

Notes to Designers

- * All Graphic files should be at least **150 DPI**.
- * All Graphic files should be created using **CMYK** color mode.
Provide PMS colors whenever possible to ensure best match.
- * It is best to **flatten all images** and **outline all text** to ensure that nothing is lost.


Bi-Fold Brochure Design

- Insert the **Outside (Cover)** of your Tri-Fold Brochure design into this template.
- Your design can fill the entire surface of the brochure within the **black cut line**. *Everything outside of the cut line will be trimmed.*
- Your print will be **folded** along the **solid blue** center line.
(Do not include it on your final design).
- Keep **important text** or details within the **safe zone**.
The blue dotted line (0.125" inside the cut line).
- You may extend **background graphics** to the **bleed zone**.
The red dotted line (0.125" outside of the cut line).
- Be mindful of any information near **USB tab gutter**.
*The green dotted lines (0.11" outside of the USB Tab).
(These lines will be used to punch-out the USB tab - They will not be printed on your final design).*

USB Tab Design

- The tear-off USB tab can be **any size or shape**.
Should be at least 1" x 1"
- The tear-off USB tab can be placed **anywhere**.
Move accordingly to fit your artwork best.
- The USB tab gutter (*green dotted lines*) **must be at least 0.125"** inside the **safe zone** (*the blue dotted line*).
- Make sure the position of the USB tab on the Outside, reflects the position of the tab on the Inside.

Inside Panel



Outside Back

**Smart Brochure
Tri-Fold - Outside (Cover)
11.00" x 8.50"**

Outside Front


Smart Brochure Tri-Fold - Inside 11.00" x 8.50"

Bi-Fold Brochure Design

- Insert the **Inside** of your Tri-Fold Brochure design into this template.
- Your design can fill the entire surface of the brochure within the **black cut line**. *Everything outside of the cut line will be trimmed.*
- Your print will be **folded** along the **solid blue** center line. *(Do not include it on your final design).*
- Keep **important text** or details within the **safe zone**. *The **blue dotted line** (0.125" inside the cut line).*
- You may extend **background graphics** to the **bleed zone**. *The **red dotted line** (0.125" outside of the cut line).*
- Be mindful of any information near **USB tab gutter**. *The **green dotted lines** (0.11" outside of the USB Tab).
(These lines will be used to punch-out the USB tab - They will not be printed on your final design).*
- The **green** text below the USB tab **must be incorporated** somewhere on the brochure. *Use our format or customize to fit your design. **Must be legible.***

USB Tab Design

- The tear-off USB tab can be **any size or shape**. **Should be at least 1" x 1"**
- The tear-off USB tab can be placed **anywhere**. Move accordingly to fit your artwork best.
- The USB tab gutter (**green dotted lines**) **must be at least 0.125"** inside the **safe zone** (*the blue dotted line*).
- Make sure the position of the USB tab on the Inside, reflects the position of the tab on the Outside.



Inside Left

Inside Center

Inside Right